



REMOTE HANDSET CODING INSTRUCTIONS BOSS



AS SHOWN - WITH ONE OR TWO BUTTONS – WITH BLACK CENTRES



(IF YOUR BUTTONS HAVE WHITE CENTRES, SIMPLY COPY DIP SWITCH PATTERN FROM YOUR OLD REMOTE/MOTOR TO THE NEW REMOTE)

TO CODE YOUR NEW REMOTE THE MOTOR PANEL

If you have access to the motor operating your door, you can use these instructions. However, if the door/gate motor is shared with other tenants at a residential/commercial complex, **do not** use these instructions.

Note: a Maximum of 20 remotes can be coded into BOSS MOTOR receivers.

To code in a new remote to a motor:

1. Ensure your new battery is installed correctly in the new remote
2. Open the cover, if any, on your MOTOR to access the CONTROL PANEL
 - a. On ROLLER DOOR motor, you may need to insert a screwdriver into the slot near the bottom of the faceplate, then:
 - i. Press and release the small LEARNING button under the large aqua button. (see Diagram 1)
 - ii. The YELLOW LED light on control panel should come ON
 - iii. Press the remote button ONCE. If the programming is successful a GREEN LED will blink twice
 - iv. Press and release the small LEARNING button again. The YELLOW LED light should go OFF
 - b. On a PANEL DOOR motor, press the RADIO SET button (see Diagram 2 over page)
 - i. With a pointed object, push and release the RADIO SET button
 - ii. The MOTOR light should come ON for 30 seconds
 - iii. Within that 30 seconds, press the remote button until the motor light FLASHES TWICE
3. Press the remote control button to test operation of the door

To code in the remote to operate 2 or 3 DOORS:

1. Remove the cover on each door's CONTROL BOX PANEL.
2. Repeat the above process using a DIFFERENT button on the remote to operate each door

TO DELETE ALL STORED CODES FROM A DOOR

Do not do this if the door is shared with other tenants at a residential/commercial complex.

1. On a ROLLER DOOR motor: turn off the power, then press and hold down the LEARNING button whilst turning the power on. The 3 LED lights on the control panel will flash – confirming all codes have been deleted
2. On a PANEL DOOR motor: hold the RADIO SET button down for 5 seconds. The motor light will flash 7 TIMES – confirming all codes have been deleted

Thank you for your purchase.

Our Customer Support team are available weekdays 8am-5pm on (07) 5476 9227 if you have any further questions.

DIAGRAM 1 : ROLLER DOOR MOTOR





DIAGRAM 2 : PANEL DOOR MOTOR



Thank you for your purchase.
Our Customer Support team are available weekdays 8am-5pm on (07) 5476 9227 if you have any further questions.